

MPX-60 USB ID Change Utility

Overview: This utility is for use when connecting 2 or more MPX-60's via USB connectivity.

NOTE: This utility is **ONLY** needed if your PC or Notebook reboots when connecting the 2nd MPX-60 or asks for a reboot when the 2nd MPX-60 is connected.

Important:

* When changing the ID, please do not connect 2 or more MPX-60's to the PC/notebook at the same time.

* If the MPX-60 goes into the firmware upgrade mode (if you connect the AC Adaptor while pressing the Standby key), the ID always becomes 1. Please don't perform a firmware upgrade with 2 or more MPX-60's connected to the PC.

Procedure:

1. Install the MPX-60 driver and one of the MPX-60 Photo Impact Printers by referring to the User's Manual. (You can use either one of the MPX-60's for installing the driver.)
2. With the first MPX-60 connected and powered on, start the "mpxid.exe".
3. Active USB drivers are displayed in the pop-up list. In this case, only one driver named "Roland MPX-60" is listed.
4. Select the driver in the list.
5. The current ID value of the selected driver is shown in the radio buttons (1-16). All the machines are set to 1 when shipped from the factory.
6. Change the ID of the machine to something other than 1 (2-16). In this case, change it to 2.
7. Click OK. The ID of the connected MPX-60 is now changed to 2.
8. Turn off and on the power of the MPX-60.
9. The "Found New Hardware" wizard appears.
10. Install the driver by referring to the User's Manual again.
11. Another driver named "Roland MPX-60 (Copy 1)" will be installed in the Printer and Faxes window. This is the driver for the MPX-60 whose USB ID was changed to 2. The existing MPX-60 driver "Roland MPX-60" is the driver for the MPX-60 whose ID is set to 1 (this would be the second machine).
12. Rename each driver to MPX-60 SNxxxxx (where xxxx = the individual serial number of each machine). This makes it easy to tell which machine is being printed to.